



1	2G2-15410-00-00	CRANKCASE COVER ASS'Y, left.	1
2	1J7-15461-00-00	GASKET, crankcase cover left.	1
3	91810-03014-00	PIN, dowel (8.5-10-14)	2
4	93102-24154-00	OIL SEAL (SD-24-40-7.4)	1
5	91316-06025-00	BOLT, hexagon socket head	11
6	1J7-15474-00-00	SEAL, air dust.	1
7	1J7-15497-00-00	PLATE, dust seal.	1
8	1J7-15417-02-00	COVER, cap.	1
9	2G2-15416-00-00	COVER, breaker plate.	1
10	91316-06030-00	BOLT, hexagon socket head	3
11	99999-01067-00	COVER, crankcase right (2G2-15431-01)	1
	2G2-15431-03-00	COVER, crankcase	1
	90201-20722-00	WASHER, plate.	1
12	1J7-15451-00-00	GASKET, crankcase cover right.	1
13	91810-03014-00	PIN, dowel (8.5-10-14)	2
14	93102-25153-00	OIL SEAL (SD-25-40-6)	1
15	2G2-15415-00-00	COVER, generator.	1
16	91810-18016-00	PIN, dowel (6.4-8-16)	2
17	91316-06018-00	BOLT, hexagon socket head	4
18	91316-06030-00	BOLT, hexagon socket head	1
19	91316-06040-00	BOLT, hexagon socket head	7
20	91316-06080-00	BOLT, hexagon socket head	4
21	90465-08116-00	CLAMP (1J7-81628-00)	2
22	1T4-81624-00-00	CLAMP.	1
23	90465-10113-00	CLAMP (1J7-81665-01)	1
24	90201-06431-00	WASHER, plate (6.2-11-1.0)	2
25	2H7-15361-00-00	GAUGE, oil level.	1