



1	2H9-25168-00-00	CASTING WHEEL, front (1.85-19) . . .	1
	2H9-25168-20-00	CASTING WHEEL, front (2H9-25168-00)	1
2	94132-19398-00	TIRE, front (3.25-19-4PR tubeless)	1
3	93900-00001-00	VALVE, rim	1
4	90560-17126-00	SPACER (341-25117-01)	1
5	1A1-25115-00-00	FLANGE, spacer	1
6	93306-30309-00	BEARING (B6303ZZ)	1
7	341-25149-00-00	CLUTCH, meter	1
8	341-25846-00-00	RETAINER, clutch meter	1
9	341-25137-00-00	RING, stop	1
10	90201-25286-00	WASHER, plate (341-25147-00)	1
11	341-25135-01-00	GEAR, drive	1
12	90201-25490-00	WASHER, plate (152-17226-00)	1
13	93105-45017-00	OIL SEAL (SDD-45-56-6)	1
14	341-25191-01-00	HOUSING, gear unit	1
15	306-25138-00-00	GEAR, meter	1
16	102-18416-00-00	WASHER	1
17	306-25136-00-00	BUSHING	1
18	341-25181-01-00	SHAFT, wheel	1
19	91401-30030-00	PIN, cotter	1
20	93306-30303-00	BEARING (B6303Z)	1
21	93102-28022-00	OIL SEAL (SD-28-47-7)	1
22	90387-17433-00	COLLAR (341-25183-00)	1
23	341-25118-00-00	COVER, hub dust	1
24	92901-14200-00	WASHER, plain	1
25	90171-14020-00	NUT, castle (90171-14006)	1
26	1A1-25398-01-00	BALANCER, wheel	} U.N.
	1A1-25399-00-00	BALANCER, wheel	
	2M0-25399-00-00	BALANCER, wheel	
27	91609-20014-00	PIN, spring	1