


21	3J3-14943-42-00	.. JET, main (#142) (3J3-14925-42)	3
22	3J3-14948-40-00	.. JET (#40)	3
23	3J3-14961-40-00	.. JET, starter (#40)	3
24	3J3-14924-00-00	.. EMULSION TUBE, slow	3
25	3J3-14947-15-00	.. STARTER, air jet	3
26	3J3-14956-00-00	.. HOLDER, jet	3
27	3J3-14928-10-00	.. JET, main air	3
28	3J3-14949-31-00	.. JET, pilot, air	3
29	3J3-14983-12-00	.. NOZZLE, starter	3
30	3J3-14921-26-00	.. NOZZLE, main	3
31	3J3-14959-00-00	.. GASKET	3
32	3J3-14171-00-00	.. PLUNGER, starter	3
33	3J3-14955-00-00	.. E-RING	3
34	3J3-14968-00-00	.. CAP	3
35	3J3-14173-00-00	.. COVER, plunger cap	3
36	3J3-14135-00-00	.. SPRING, plunger	3
37	3J3-14996-00-00	.. BRACKET	1
38	3J3-14998-00-00	.. BUSH	1
39	3J3-14973-00-00	.. BUSH	2
40	3J3-14905-00-00	.. LEVER, starter	3
41	3J3-14991-00-00	.. SCREW	3



No.	Number	Description	Qty.
42	3J3-14989-20-00	ORIFICE, air vent	6
43	97801-05014-00	SCREW, pan head	15
44	97801-05006-00	SCREW, pan head	12
45	97801-05016-00	SCREW, pan head	12
46	3J3-14922-00-00	SCREW, throttle	2
47	3J3-14951-00-00	WASHER	2
48	3J3-14952-00-00	WASHER	2
49	3J3-14133-00-00	SPRING, throttle stop	2
50	3J3-14122-00-00	SCREW, throttle	1
51	3J3-14938-00-00	SPRING	1
52	3J3-14934-00-00	SPRING, throttle stop	1
53	3J3-14940-00-00	DIAPHRAGM ASS'Y.	3
54	3J3-14978-00-00	SHAFT, starter lever	1
55	3J3-14988-00-00	NIPPLE	2
56	97801-05012-00	SCREW, pan head	6
57	97801-06016-00	SCREW, pan head	6
	3J2-14118-00-00	PLUG, blind	1