



No.	Number	Description	Qty.
1	2H9-25168-20-00	CAST WHEEL front(1.85-19)....	1
2	90560-17126-00	SPACER	1
3	1A1-25115-00-00	FLANGE, spacer 1.....	1
4	93105-45017-00	OIL SEAL	1
5	93306-30309-00	BEARING (B6302ZZ)	1
6	93306-30303-00	BEARING (B6302Z).....	1
7	341-25149-00-00	CLUTCH, meter.....	1
8	341-25846-00-00	RETAINER, clutch.....	1
9	93102-28022-00	OIL SEAL	1
10	94132-19398-00	TIRE (3.25-19).....	1
11	93900-00001-00	VALVE, rim.....	1
12	341-25190-01-00	GEAR UNIT ASS'Y	1
13	341-25118-00-00	COVER, hub dust	1
14	1A1-25398-01-00	BALANCER, wheel (20G).....	1
	1A1-25399-00-00	BALANCER, wheel (10G).....	1
	2M0-25399-00-00	BALANCER, wheel (30G).....	1
15	341-25181-01-00	AXLE, wheel.....	1
16	92901-14200-00	WASHER, plain	1
17	90171-14020-00	NUT, shaft (90171-14006).....	1
18	91401-30030-00	PIN, cotter	1
19	90387-17433-00	COLLAR	1