



1	3J3-22110-01-33	REAR ARM COMP.	1
2	93332-00010-00	BEARING	2
3	93102-25017-00	OIL SEAL	2
4	90387-17543-00	COLLAR	2
5	1J7-22141-00-00	SHAFT, pivot	2
6	1J7-22143-00-00	NUT.....	2
7	2H7-2219X-00-00	COVER	2
8	2H7-22189-00-00	BOOT, rubber.....	1
9	90506-07136-00	SPRING, tension.....	1
10	90506-07135-00	SPRING, tension.....	1
11	97303-08035-00	BOLT	1
12	92906-08100-00	WASHER, spring.....	1
13	3J3-22210-00-00	SHOCK ABSORBER ASS'Y, rear	1
14	3J2-22212-00-00	. SPRING.....	1
	3J2-22212-A0-00	. SPRING.....	1
15	3J3-22210-10-00	SHOCK ABSORBER ASS'Y, rear	1
16	3J2-22212-00-00	. SPRING.....	1
17	90176-10013-00	NUT, crown	1
18	90201-10142-00	WASHER, plate.....	2
19	90106-10030-00	BOLT	1
20	92903-10100-00	WASHER, spring.....	1
21	90201-10140-00	WASHER, plate.....	1
22	90176-10009-00	NUT, crown	2