


Ref. No	Part Number	Description	Qty	A M N
1	2F3-13336-02-00	HOUSING, rotor	1	
2	93603-17070-00	PIN, dowel	1	
3	2F3-13310-01-00	ROTOR ASS'Y 1	1	
4	2F3-13306-00-00	PUMP COVER COMP.	1	
5	91830-22016-00	PIN, dowel	2	
6	91316-06020-00	BOLT	4	
7	91316-06040-00	BOLT	2	
8	93603-07073-00	PIN, dowel	1	
9	1J7-13338-00-00	SEAL	1	
10	1J7-13483-00-00	PLUNGER, relief	1	
11	1J7-13484-00-00	SPRING, relief	1	
12	2F3-13411-00-00	STRAINER, oil	1	
13	1J7-13412-01-00	HOUSING, strainer	1	
14	91316-06035-00	BOLT	2	
15	98503-05012-00	SCREW, pan head (98501-05012)	3	
16	1J7-13417-01-00	COVER, strainer	1	
17	1J7-13414-00-00	GASKET, strainer cover	1	
18	91316-06025-00	BOLT	2	
19	91316-06055-00	BOLT	1	
20	214-11198-01-00	GASKET	1	
21	1J7-13337-01-00	PLATE, baffle lower	1	
22	92503-06010-00	SCREW, pan head (92501-06010)	4	
23	2F3-13171-00-00	PIPE, delivery 2	1	
24	90401-18040-00	BOLT, union	1	
25	90401-10054-00	BOLT, union	1	
26	90430-18130-00	GASKET	2	
27	90430-10128-00	GASKET	1	
28	90430-15129-00	GASKET	1	

OIL PUMP



Ref. No	Part Number	Description	Qty.
29	2G2-13161-00-00	PIPE, delivery 1	1
30	90401-10013-00	BOLT, union	1
31	90401-10004-00	BOLT, union	1
32	90430-10027-00	GASKET	4
33	1J7-13325-01-00	GEAR, pump driven (11T/47T)	1
34	1J7-13313-00-00	HOUSING	1
35	92603-06018-00	SCREW, flat head (92701-06018)	2
36	90201-20276-00	WASHER, plate	1
37	1J7-13324-00-00	GEAR, pump drive (46T)	1
38	90201-26600-00	WASHER, plate	1
39	90170-26191-00	NUT	1
40	90340-14009-00	PLUG, straight	1